

LMS-033
NB Rear Tow Hook
Rev-01

Installation Instructions

1. Remove all parts from the packaging. There will be
 - a. Tow Hook
 - b. Inner mounting bracket
 - c. 2 nuts (not shown)



2. Slide the inner mounting bracket up into the frame rail on the drivers side of the car as shown.



3. Slide the tow hook over the bolts, and install the nuts. Toque nuts to 30 ft-lbs.



