



NOTE: Installation of rivet nuts will require a rivet nut tool. A rivet nut tool can be purchased from your favorite tool supplier.

1. Mark out and location the location of the jacking point. While it can be mounted anywhere along the pinch-weld of the car, we recommend directly below the door mirror, as this is closest to the balance point.
2. Using the jacking block as a template, mark the needed hole locations.
3. Drill out the holes with a 25/64" drill
4. Install and crimp the rivet nuts into the holes.



5. Mount the jack point with the supplied M6 bolts. Toque to 125 in-lbs.

