



Battery

Speaker Box

FUSE

12V+

SUB WIRE -

SUB WIRE +

REAR RIGHT SPEAKER (PAIR)

REAR LEFT SPEAKER (PAIR)

AMP TRIGGER

AMP

PRE-AMP OUT +

PRE-AMP OUT -

Radio